

**Note:** Be sure to change the default master code to your personal master code before you start programming the AT10/AT1 Series locks.

## How to Add a user fingerprint

1. First you are going to press the “SOLITY” button two (2) times. The “SOLITY” button will light up with a steady blue light.
2. You are then going to enter your master code.
3. After that you will press the “SOLITY” button one (1) time and the “SOLITY” button will light up with a still green light.
4. You are now going to press the number zero (0), the “SOLITY” button will flash with a green light one (1) time.
5. To add only one fingerprint:
  - a. Select the number one (1) and then scan the desired finger you wish to use four (4) times on the fingerprint scanner.
6. To add multiple fingerprints at the same time:
  - a. In this case, follow steps one-four (1-4) then you need to press the number two (2) after you have pressed the number zero (0) and then start to scan fingerprints four (4) times for each individual and when you are finished, press the “SOLITY” button one (1) time, it will flash with a green light one (1) time.