

## GT5 Series/GT10 Series

### ADD FINGERPRINT

**\*Note:** Any delay in pressing the numbers on the keypad will time out the lock. You will have to restart the entire process.

1. Slide up to open the back panel where the batteries are located
2. Locate and press the “Register” button 
3. Enter Administrator code. If you have not changed the Administrator code. It should be “123456.”
4. Press “#” then “3.”
5. You are going to want to assign the fingerprint a number in chronological order. For example, if this is the first fingerprint, you would press “1” then “#”. In the future, if you wish to delete a certain fingerprint, you have it assigned to a number, which will be asked during the deletion of fingerprint deletion process.
6. Using the desired finger you select, you will press the finger 3 times on the finger sensor.



7. A fingerprint is created

### Delete Fingerprint

**\*Note:** Without an assigned fingerprint number, the lock will show an error and will return back to pressing the assigned number

1. Slide up to open the back panel where the batteries are located
2. Locate and press the “Register” button 
3. Enter Administrator code. If you have not changed the Administrator code. It should be “123456.”
4. Press “#” then “3.”
5. When you created the fingerprint, you assigned a number to it. You are going to press the assigned number.
6. Press “\*”
7. The fingerprint is deleted