



## Sound Volume Setting

**\*Note:** This sound is for daily opening/closing sounds

1. Enter Administrator Pin Code
2. Press “\*”
3. Press “3” to Increase volume
4. Press “6” to Decrease volume