



Auto-Lock Time Setting on App


1. Open the Smart Solity App on your phone



2. Make sure to select which lock you want to access



3. You are going to click on “Lock Setting” near the bottom of the screen




4. Scroll down towards the bottom and click on “Automatic Lock”




5. If Auto-Lock is off, turn it on

6. You will see two options. One that says “Immediate” and the other that says “Timer”



7. To set your lock to a certain time click “Timer” then select the time using the “+” sign



8. Click “Confirm” and your lock time setting is enabled.