

Note: In order to start programming the AT Series you must first change the master code to your personal master code.

HOW TO ADD USER CODE

1. The first thing you will need to do is press the “SOLITY” button two (2) times. The button will light up green and stay lite.
2. You are then going to enter your “New Master Code” that you have created.
3. After you enter your master code, you are going to press the “SOLITY” button one (1) time, the “SOLITY” button will flash one time with a green light
4. You are then going to press the number 2 button
5. Now you are going to create your user code that you want to use to unlock the door. (Note: User code must be 6 to 8 digits long).
6. When you finish creating your user code, next you will press the “SOLITY” button one (1) time. Once again the “SOLITY” button will flash with a green light again.
7. After this you are going to enter the user code you have created one (1) more time.
8. Finally, press the “SOLITY” button one more time to complete adding your user pin code. The “SOLITY” button will flash with a green light.